




LOWER OVEN PARTS

For Models: RBD275PDB7, RBD275PDQ7
(BLACK) (DESIGNER WHITE)

27" BUILT-IN ELECTRIC
DOUBLE OVEN
STD-CLEAN LOWER
SELF-CLEAN UPPER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LOWER OVEN PARTS


For Models:RBD275PDB7, RBD275PDQ7
(BLACK) (DESIGNER WHITE)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
NOTE: The screws and nuts required to attach a part are listed immediately following that part.			10	4451664	Fan & Bracket Assy.	43	4451397	Base, Chassis
				4449809	Screw		4449154	Screw
			11	4452368	Oven Light Assy	49	4448933	Retainer, Gasket
			12	4452166	Bulb, Light		4449154	Screw
			13	4452165	Lens, Light	50	4451747	Cover, Back
1		Trim, Side		4449809	Screw		4449809	Screw
	4450850	RH Black	14	4451739	Frame, Front	51		Trim, Bottom
	4450851	RH White		4449040	Screw		4448475	Black Model
	4450853	LH Black		4450118	Nut		4448476	White Model
	4450854	LH White	15	4450492	Gasket, Door		4159465	Screw
		Screw	19	4451477	Support, Insulation	53	4449845	Support, Bracket
	4449747	Black Model	25	4454691	Side, Chassis		4449809	Screw
	4449041	White			(R.H. & L.H.)	FOLLOWING PARTS NOT ILLUSTRATED		
3		Receiver, Hinge		4449809	Screw	INSULATION		
	4454664	Left Hand	26	4452233	Back, Chassis		4449315	Insulation, Wrap
	4454665	Right Hand		4449809	Screw		4450364	Insulation, Back
4	4448520	Bumper, Door	27		Liner, Oven			
7	4455189	Top, Chassis			(Not serviceable)			
9	4452159	Tube, Vent	29	4451665	Sensor			
	4159450	Screw		4449154	Screw			
			37	4451354	Fuse-Thermal			
				4449809	Screw			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UPPER OVEN PARTS

For Models: RBD275PDB7, RBD275PDQ7
(BLACK) (DESIGNER WHITE)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UPPER OVEN PARTS

For Models:RBD275PDB7, RBD275PDQ7
(BLACK) (DESIGNER WHITE)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1		Reciever, Hinge
	4454664	Left Hand
	4454665	Right Hand
4	4448520	Bumper, Door
5	4451422	Switch, Micro
6	4452224	Solenoid
7	4451426	Switch, Micro
8	4451537	Spring, Latch
9	4452158	Tube, Vent
10	4452165	Lens, Light
	4159450	Screw
11	4450706	Oven Light Assy
12	4452166	Bulb, Light
14	4451739	Frame, Front
	4449040	Screw
15	4449371	Gasket, Door

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

19	4451477	Support, Insulation
	4449809	Screw
20	4451605	Cap, Spacer
21		Rail, Side
	4450581	Right Side
	4450582	Left Side
	4448444	Grommet
	4449154	Screw
24	4451896	Latch Assy
	4449809	Screw
25	4454691	Side, Chassis
		(R.H. & L.H.)
	4449809	Screw
26	4452233	Back, Chassis
	4449809	Screw
27		Liner, Oven
		(Not serviceable)
29	4451665	Sensor
	4449154	Screw
34	4452266	Vent, Center

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

37	4451442	Thermostat (TOD)
		(Temp.) SPST
	4449809	Screw
43	4451397	Base, Chassis
	4449809	Screw
49	4448933	Retainer, Gasket
	4449154	Screw
50	4451747	Cover, Back
	4449809	Screw
53	4449845	Support, Bracket
	4449809	Screw


FOLLOWING PARTS NOT ILLUSTRATED

INSULATION

4449315	Insulation, Wrap
4450364	Insulation, Back

LOWER OVEN DOOR PARTS

For Models: RBD275PDB7, RBD275PDQ7
(BLACK) (DESIGNER WHITE)



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	4451718	Door Liner
3	4449253	Glass, Inner

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

5	4451670	Retainer, Glass
	4449809	Screw
6	4454945	Hinge, Door
	4449743	Screw
12		Door Glass, Assy
	4452062	Black Model
	4452063	White Model


Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

13		Door Handle
	4448405	Black Model
	4448406	White Model
14	4450813	Bracket, Handle
	4451040	Screw
21	4451673	Seal, Door Top
23		Retainer, Clip
	4450863	Black Model
	4450864	White Model

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UPPER OVEN DOOR PARTS

For Models: RBD275PDB7, RBD275PDQ7
(BLACK) (DESIGNER WHITE)



Illus. No. Part No. DESCRIPTION

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1 4451718 Door Liner
2 4454945 Hinge, Door
4449743 Screw
3 4449253 Glass, Inner

Illus. No. Part No. DESCRIPTION

4 4451721 Insulation, Door
5 4451670 Retainer, Glass
4449809 Screw
7 4449257 Glass, Inner
12 4452062 Black Model
4452063 White Model
13 4448405 Black Model
4448406 White Model


Illus. No. Part No. DESCRIPTION

14 4450813 Bracket, Handle
4451040 Screw
19 4450361 Shield, Heat
4449809 Screw
20 4451668 Retainer, Glass
4449809 Screw
21 4451673 Seal, Door Top
23 4450863 Black Model
4450864 White Model
24 4455256 Glass, Inner

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL OVEN PARTS

For Models:RBD275PDB7, RBD275PDQ7
(BLACK) (DESIGNER WHITE)




Illus. No.	Part No.	DESCRIPTION
2	4452154	Element, Broil
	4449154	Screw
3	3147563	Grill, Broiler
4	3147845	Pan, Broiler
6	4448715	Rack, Oven
7	4452153	Element, Bake
	4449154	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: RBD275PDB7, RBD275PDQ7
(BLACK) (DESIGNER WHITE)



Illus. No.	Part No.	DESCRIPTION
---------------	-------------	-------------

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	Control Panel Assy. W/Membrane Switch
	4451967 Black Model
	4451968 White Model
	4159465 Screw
2	4451033 Gasket, Control Panel
3	4451991 Microcomputer
	4449745 Screw
	4449899 Screw


LITERATURE PARTS

LIT4450410	Installation Instructions
LIT4450568	Use & Care Guide (Oven)
LIT4451887	Tech Sheet (Oven)
LIT3191638	Safer Cooking Tips

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: RBD275PDB7, RBD275PDQ7
(BLACK) (DESIGNER WHITE)



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	4451759	Vent, Exhaust
	4449040	Screw
2	6610168	Blower
3	4451758	Foam, Block
4	4455178	Elbow, Vent-Top
5	4455177	Elbow, Vent-Bottom
6	4451789	Plate, Mounting

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

7	4451891	Transformer, Control
11	4449868	Block, Terminal
	3400016	Screw
13	4448548	Vent, (Control Panel)
	4450038	Screw
14	4451597	Right
	4451598	Left
	4449809	Screw
	4449154	Screw

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

15	4452244	Back, Control
	4449809	Screw
16	4450550	Cover, Top Rear
	4449809	Screw
17	4448664	Clamp
	4449809	Screw
	112432	Nut
18	4452366	Cover, Top Front
	4449809	Screw
19	4454943	Plate, Mounting Fan
20	4451985	Suppressor
21	4455191	Plate, Service

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models:RBD275PDB7, RBD275PDQ7
(BLACK) (DESIGNER WHITE)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

PAINT, TOUCH-UP (1/2oz.)

	72017	White
	261869	Cord Brown
	72032	Black

PAINT, SPRAY

	350930	White
	261900	Citrine White
	830864	Black

ADHESIVE

	591014	Adhesive Loctite (1/3 oz.)
	482338	Sealer, Silastic (3 oz.)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

SPLICING WIRES--25FT.

LENGTH

242828	Wire (12 Ga. 150 c Black)
242820	Wire (14 Ga. 150 c Black)
242821	Wire (14 Ga. 150 c Blue)
242822	Wire (14 Ga. 150 c Brown)
242830	Wire (14 Ga. 200 c Brown)
242823	Wire (14 Ga. 150 c Green)
242824	Wire (14 Ga. 150 c Orange)
242829	Wire (12 Ga. 150 c Red)
242825	Wire (14 Ga. 150 c Red)
242831	Wire (14 Ga. 200 c Red)
242826	Wire (14 Ga. 150 c White)
242827	Wire (14 Ga. 150 c Yellow)
242832	Wire (14 Ga. 200 c Yellow)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

WIRING HARNESS PARTS

4455350	Harness, Wire (Main)
4450953	Conduit, Double
4448664	Clamp
4449809	Screw
112432	Nut
4450800	Screw, Ground
4450814	Fuse Assy (Service Only)
4452222	Spacer, Harness
4454835	Tie, Cable
4451761	Support, Wiring

Miscellaneous

814381	Hinge Pin Kit
4448950	Screw, Install (4)